

# MTP138 QUICK GUIDE



ITEM	NAME	DESCRIPTION
1	Main Volume Knob (MAIN VOL)	Adjusts the volume of the main radio. Detent turns the MTP OFF.
2	Monitor (MON)	Bypasses Squelch Threshold and Channel Signaling allowing all transmissions to be heard.
3	Channel Recall (RCL)	Returns to the previous channel.
4	Radio Recall (MAIN GUARD)	Switch between MAIN and GUARD for transmit and edit.
5	Transmit Power (HI LO)	Changes transmit power.
6	Guard Volume Knob (GUARD VOL)	Adjusts the volume of the guard radio.
7	Rotary Selector (PUSH   ENTER)	Changes channel, navigates, and modifies options.
8	Keypad and MENU	Shows/hides the Menu. Changes channel, navigates, and modifies options.
9	Data Port (DATA)	USB Type-C port used for Profile Import/Export, Error Log Export, and Firmware Updates.

FUNCTION	KEYS
Edit RX Frequency	MENU [3 DEF] [3 DEF] Enter the frequency [PUSH ENTER]
Edit TX Frequency	MENU [3 DEF] [4 GHI] Enter the frequency [PUSH ENTER]
Edit RX Tone	MENU [3 DEF] [5 JKL] Select CTCCS TONE, DCS CODE or NONE [PUSH ENTER] Rotate to or type in desired TONE/CODE [PUSH ENTER]
Edit TX Tone	MENU [3 DEF] [6 MNO] Select CTCCS TONE, DCS CODE or NONE [PUSH ENTER] Rotate to or type in desired TONE/CODE [PUSH ENTER]
Change Zone	MENU [4 GHI] Rotate to Zone [PUSH ENTER]
Return Home	MAIN GUARD Or push your PTT

**Contact Technical Support:**  
1-888-763-1088 ext. 2 or [support@aem-corp.com](mailto:support@aem-corp.com)

- Unique Software Key
- Agile Edit Quick Guide
- Pre-Made Channel Lists
- Programming Assistance

**AEM Radio Profile Editor:**  
<https://software.aem-corp.com/mtp13xx/editor>

#100-966 Crowley Ave Kelowna, British Columbia, Canada V1Y 0L1

[aem-corp.com/radio](https://aem-corp.com/radio)